

GETTING STARTED

Smoke and Heat Sensor

The Smoke and Heat Sensor is always monitoring for smoke or a rapid increase in temperature, even when your system is disarmed. Follow the instructions below to get protected in no time:

- 1 Select a location on the ceiling or wall of a common hallway shared by multiple bedrooms or in a central room in the home.
- 2 Make sure the surface is clean and dry. If you're placing on a ceiling, place it 4 inches away from the wall. If on the wall, place 4 to 12 inches below the ceiling.
- 3 Once you've removed the wax backing from the adhesive, press the sensor firmly against the wall or ceiling for 30 seconds.

Do Not: Place the sensor in any of the following areas: in a kitchen or garage; near a ventilation source such as an exhaust fan; near a shower or another potentially humid area; near a furnace, space heater or hot water heater.