


GETTING STARTED

Talking Remote Touchpad

Use as a secondary control panel for homes with multiple levels or entrance points. It can be mounted or used as a portable remote inside your home.



- 1 **System Status** - Press to hear any system messages.
- 2 **Doors + Windows Button** - Press once to arm in Stay Mode – arming your Door & Window and Glass Break Sensors with a 30-second entry delay. Press twice to arm in Stay Mode with no entry delay.
- 3 **Motions Button** - Press to arm in Away Mode – arming your Door & Window, Glass Break and Motion Sensors.
- 4 **Disarm** - Press and then enter your 4-digit code to disarm the alarm system.
- 5 **Emergency Buttons** - Press and hold both at the same time to trigger a panic alarm.

NEED HELP? WWW.FRONTPOINT.COM/HELP